



INSTALLATION ESSENTIALS FOR ENGINEERED FLOORING

Heritage Mill Engineered Wood Flooring can easily be installed by either floating, full spread glue or nail down. Here are additional items recommended for each type of installation:

Looking to buy it now? Scroll over the to purchase the product!

FLOATING INSTALLATIONS

UNDERLAYMENTS:

good



Unison
#70-025

better



Black Jack
#70-026

best



Airguard
#70-105

EXTRA PROTECTION:



Moisture Barricade
#70-115

Tongue & Groove
Adhesive
#1406-P



INSTALLATION TOOLS:

Flooring Installation Kit
#10-28



Tapping Block
#10-17-8



Pull Bar
#10-18-8



FULL SPREAD INSTALLATIONS

ADHESIVES:

good



Engineered Wood
Flooring Adhesive
#1407-4

better



Wood and Bamboo
Flooring Adhesive
#R1509-4

best



4-in-1 Wood
Flooring Adhesive
#R1535-4

INSTALLATION TOOLS:

Use with
1407 & R1509



1/4" x 1/4" x 1/4"
Flat Top V-Notch Trowel
#10142-12

Use with
R1509



1/4" x 1/4" x 1/4"
Square Notch Trowel
#10113X

Use with
R1535



1/4" x 3/16"
Tiger Tooth® Trowel
#10144



Adhesive Remover
Towelettes
#R5505-VV

Tapping Block
#10-17-8



NAIL/STAPLE INSTALLATIONS

Nail/Staple Installations require the use of a 15 lb. asphalt felt



18 Gauge
Floor Stapler
#461A

Use with
461A



1/4" Crown
Flooring Staples:
#46196 (1")
#46197 (1-1/4")
#46198 (1-1/2")



18 Gauge
Floor Nailer
#418A

Use with
418A



"L" Head
Flooring Cleats:
#41801 (1-1/4")
#41802 (1-1/2")
#41803 (1-3/4")