

DIY FRIDAYS

PROJECT : Floating Install- Subfloor Leveling for Low Spots

#DIY101

TOOLS & MATERIALS: Level, Tape Measure, Leveling Compound, Mixing Paddle, Bucket, Trowel

Step 1



Use level and tape measure to ensure floor is flat to within 3/16" in an 8' radius.

Step 2



Mix leveling compound per manufacturer specifications.

Step 3



Pour out the proper amount of leveling compound.

Step 4



Use appropriate trowel to spread self leveling compound

Step 5



Once compound is dry, roll out the Roberts Airguard underlayment

Step 6



Install your new Heritage Mill Flooring!