

DIY FRIDAYS

PROJECT : Serving Tray From Left Over Flooring

#DIY103

TOOLS & MATERIALS: Tape Measure, Pencil, Miter or Hand Saw, Left Over Flooring, 1-1/4" Screws, Drawer Pulls (2 of your choice)

Step 1



Using left over material, measure out 3-24" base pieces and 2-12" end pieces of flooring, and cut them to length.

Step 2



Mark and drill holes for the drawer pulls so that they are centered on the 2 – 12" end pieces.

Step 3



Attach the drawer pulls on the 12" end pieces using the provided hardware.

Step 4



Engage the 24" base pieces together, just as you did your floor.

Step 5



Attach the 12" end pieces to each end of the base with 1-1/4" screws from the bottom side.

Step 6



Enjoy your Serving Tray and Have a nice reminder of your flooring install.